

BEMERO


STUDIO & STAGE ACCESSORIES

NOTEBOOK / PROJECTOR STAND

Model: PS-9010BK

Assembly

1. Insert the upper upright into the lower assembly and tighten the thumb wheel to set the height as required.



2. Remove the bolt and thumb wheel from the adjuster quadrant.
3. Lower the table assembly over the adjuster so the adjustment slots align with the cross tube.
4. Insert the bolt through the slots and fit the thumb wheel.
5. Adjust the angle of the table as required and fully tighten the thumb wheel.

